

# simalube IMPULSE quick instruction guide for installation, removal, refill and disposal

# Define installation type and accessories



Direct Installation

Indirect Installation



simalube lubricators and simalube IMPULSE can be installed in all positions, even underwater.



("Calculation Pro" is available at www.simalube.be, in the App Store, and in the Android Market.)

### **Prepare Iubrication point**



**Clean lubrication point** 



Remove connector nipple



Screw in reducing nipple and seal lubrication point



**Lubricate the grease lines with a grease gun** (fill tubes completely)

#### Install and activate simulube and IMPULSE



Screw the IMPULSE onto lubrication point (1) IMPULSE logo must face the front



Cut off plug



Activate dispensing time with 3 mm Allen key



Write in activation date



Insert the battery pack



Screw the lubricator onto the IMPULSE



Device will be activated, green LED will blink 2x

1) The first pump cycle will begin within 30 seconds



Check simulube and IMPULSE regularly





## Replace the lubricator



Replace or refill the empty lubricator



Remove the used battery pack and replace it with a new one



Screw refilled or new lubricator onto the lubrication point

# Period of use of the simulube IMPULSE:

10x simalube dispensing cycles



3 years from the production date

or



#### Correct disposal of the simalube and IMPULSE



Dispose empty lubricator





a) Remove cover disk
 b) Remove gas generator
 with a socket wrench
 (SW21 mm)





Dispose of intact gas generator in battery recycling and empty housing in plastic recycling.

recycling.
(Warning: dispose of leftover grease separately)



Dispose simalube IMPULSE







Dispose of used battery pack in battery recycling and IMPULSE device in accordance with Directive 2002/96/EG (WEEE).